



FIG. 31.—Cabet posterior wire splint applied with supination of the foot. When used for injuries of the ankle and tarsus the entire splint should be twisted so that the foot piece will be inclined and hold the foot in the position of varus. The object of this position is to overcome the natural tendency toward the valgus deformity with the subsequent development of flat foot.